

Inspection Criteria


The compressor should be installed behind and below the lower end of the side member.

Reason


When the compressor is installed behind the front end of the side member avoiding the horizontal surface of the side member, risk of damaging the compressor is reduced when the side member is crushed or bent inward due to a collision.

Good Example

The compressor is located behind the front end of the side member and outside of the horizontal surface of the side member.




The compressor is located behind the front end of the side member and outside of the horizontal surface of the side member.



Poor Example

The compressor is located at the front end of the side member and inside of the horizontal surface of the side member.



The compressor is located behind the front end of the side member but overlapped inside of the horizontal surface of the side member.

